

Product 711197



711197 Passive holder with tilt swivel

Keep your device in a passive holder and you will always have it within easy sight and reach! Neat, discreet and convenient. Custom made holder with a perfect, firm fit. You have full access to the camera and all buttons and outlets when the device is in the holder. You can connect a charging cable or portable handsfree to the device when it is in the holder.

The holder is equipped with a tilt swivel so you can easily adjust the angle for better viewing, or switch between portrait and landscape mode. Tilts 17° and swivels 360°. Mounting plate 42x50 mm with 4 mm AMPS-holes. Made of high grade black ABS plastic. Color: black. Made in Sweden. Attach onto a high strength ProClip Mounting Platform or a Pedestal Mount.

EAN: 7320287111972

Item no 711197 fits:

Zebra TC21 (For all countries)

Zebra TC26 (For all countries)

INSTALLATION INSTRUCTIONS

1.



2.



3.



4.



Please read all of the instructions and look at the pictures before attaching the holder.

1. Loosen the screw in the center of the holder so you can remove the tilt swivel attaching plate on the back.

2. Place the attaching plate onto the desired position. Screw the attaching plate into place with the enclosed screws.

3. Place the holder over the attaching plate so the screw fits in the hole in the tilt swivel. Tighten the screw until the holder is firmly in place, but still can be adjusted.

4. The holder is in place.
